

## **HONDA OBDII DTC**

P1106	BARO Circuit Range/Performance
P1107	BARO Circuit Low Input
P1108	BARO Circuit High Input
P1121	Throttle Position Lower Than Expected
P1122	Throttle Position Higher Than Expected
P1128	MAP Lower Than Expected
P1129	MAP Higher Than Expected
P1149	Primary HO2S (Sensor 1) Circuit Range/Performance Problem
P1162	Primary HO2S (No. 1) Circuit Malfunction
P1163	Primary HO2S (No. 1) Circuit Slow Response
P1164	Primary HO2S (No. 1) Circuit Range/Performance
P1165	Primary HO2S (No. 1) Circuit Range/Performance
P1166	Primary HO2S (No. 1) Heater System Electrical
P1167	Primary HO2S (No. 1) Heater System
P1168	Primary HO2S (No. 1) LABEL Low Input
P1169	Primary HO2S (No. 1) LABEL High Input
P1253	VTEC System Malfunction
P1257	VTEC System Malfunction
P1258	VTEC System Malfunction
P1259	VTEC System Malfunction
P1297	Electrical Load Detector Circuit Low Input
P1298	Electrical Load Detector Circuit High Input
P1300	Multiple Cylinder Misfire Detected
P1336	CSF Sensor Intermittent Interruption
P1337	CSF Sensor No Signal
P1359	CKP/TDC Sensor Connector Disconnection
P1361	TDC Sensor Intermittent Interruption
P1362	TDC Sensor No Signal
P1366	TDC Sensor No. 2 Intermittent Interruption
P1367	TDC Sensor No. 2 Signal
P1381	Cylinder Position Sensor Intermittent Interruption
P1382	Cylinder Position Sensor No Signal
P1456	EVAP Emission Control System Leak Detected (Fuel Tank System)
P1457	EVAP Emission Control System Leak Detected (Control Canister System)
P1459	EVAP Emission Purge Flow Switch Malfunction
P1491	EGR valve Lift Insufficient Detected
P1498	EGR Valve Lift Sensor High Voltage
P1508	IAC Valve Circuit Failure
P1509	IAC Valve Circuit Failure
P1519	Idle Air Control Valve Circuit Failure
P1607	EGM/PGM Internal Circuit Failure A
P1655	SEA/SEFA/TMA/TMB Signal Line Failure

P1660 A/T FI Signal A Circuit Failure

P1681 A/T FI Signal A Low Input

P1682 A/T FI Signal A High Input

P1686 A/T FI Signal B Low Input

P1687 A/T FI Signal B Low Input